




AXIS T94K01D Pendant Kit

Installation Guide



1x




1x



2x




1





AXIS T94K01D Pendant Kit

2




3






AXIS T94K01D Pendant Kit


6




7




8



9




10




AXIS T94K01D Pendant Kit




11



12



AXIS P32-V/-LV




1x



2x

1




2x


T20






AXIS T94K01D Pendant Kit



3




4




AXIS T94K01D Pendant Kit


5




6




7




8





9



10






11



AXIS T94K01D Pendant Kit


AXIS P33-V




1x




2x



2




3




AXIS T94K01D Pendant Kit

4



5



2x

